

mpf anlagen von: +49 0105 303020

4

2



1. *Chlorophyll a* (Chl *a*)

Instruction
Aim A 6 turns till $O_2 \times 7$ mm the first 3 turns
wound together with sec A and the last 3 turns
together with sec B.

天

prim A start 5.6 stop 3.4.
sec A 3 turns foil 0.2 x 7 mm start 7 stop 10
sec B 3 turns foil 0.2 x 7 mm start 8 stop 11

Tape two layers
sec B and sec C is wound in the same layer with distance between them.
sec B 6 turns $\phi 0.2$ mm. Cut start 1 stop 2
sec C 2 turns $\phi 0.2$ mm. Cut start 12 stop
Tape turn layers

sec B and sec C is joined in the same layer with distance between them.

see C 2 turns 003 mm. Cnls start 12 stop 9

Tape two lanes

[illegible]